

Sealants

1. Clean grooves with an **air slurry polisher**
2. Neutralize—3 seconds with typical acid
3. Wash-dry
4. If still stained, cut prep and restore—if not
5. Acid etch
6. Wash-dry
7. Place glutaraldehyde/HEMA
8. Place unfilled liquid resin and blow
9. Place fully filled resin— use the typical resin you use for class I or II restorations or higher filled flowables